

Swaging mandrels for 4200-serie fittings



Product info
Product group

To control that the swaging has resulted in
900

To control that the swaging has resulted in the right internal collapse. GO-side should pass through the fitting to make sure that the swaging is not overdone. The STOP-side should stop in the middle of the tail to ensure that the swaging is sufficient.

Part no	Dimension (Inch)
90150004	1/4"
90150006	3/8"
90150008	1/2"
90150010	5/8"
90150012	3/4"
90150016	1"
90150020	1 1/4"
90150024	1 1/2"
90150032	2"
90150305	3/16"

