



TRYCKKLASSER SKÄRRINGSKOPPLINGAR – Tryckklasserna anger kopplingar för rör Ø yttre

			LL				L								S											
			4	5	6	8	6	8	10	12	15	18	22	28	35	42	6	8	10	12	14	16	20	25	30	38
6001	6003	6006																								
6007	6008	6009																								
6010	6011	6013																								
6014	6016	6017																								
6021	6024	6027																								
6034	6035	6036																								
6041	6042	6043																								
6044	6045	6046																								
6047	6048	6049	100																							
6050	6051	6060																								
6061	6070	6071																								
6087	6089	6090																								
6092	6101	6102																								
6105	6107	6109																								
6130	6185	6216																								
6217	6218	6219																								
6537																										
6088	6172		100					400				315		250					630			400			315	
6110	6111	6116						400				315		250					400			315		250		
6118	6119																									
6083	6086											315		250					630*			400		250		
6103	6104											315							630							
6018												315		250		160			315			250		200	160	
6002												250		160		100			630			400		250		
6128			100									250		160					250				160			
6023	6033													160									400		315	
6112	6114											250							400**					250**		
6118	6119		100									400		315		250			400			315		250		
6120	6121	6123										250		160		100						400		250		

* = Säkerhetsfaktor 3

** = Säkerhetsfaktor min 1,6

GÄNGSTORLEK FÖR SKÄRRINGSKOPPLINGAR

Rörstorlek	Gänga
4LL	M8 x 1,0
5LL	M10 x 1,0
6LL	M10 x 1,0
8LL	M12 x 1,0
6L	M12 x 1,5
8L	M14 x 1,5
10L	M16 x 1,5
12L	M18 x 1,5
15L	M22 x 1,5
18L	M26 x 1,5
22L	M30 x 2,0
28L	M36 x 2,0
35L	M45 x 2,0
42L	M52 x 2,0
6S	M14 x 1,5
8S	M16 x 1,5
10S	M18 x 1,5
12S	M20 x 1,5
14S	M22 x 1,5
16S	M24 x 1,5
20S	M30 x 2,0
25S	M36 x 2,0
30S	M42 x 2,0
38S	M52 x 2,0